


# AOK Platinum Mat Stand



## IMPORTANT NOTE

Finger tighten all bolts initially. Do not fully tighten any bolts until you are fully assembled. Once fully assembled gradually tighten each bolt and then its diagonal opposite. You may need to go to each bolt/nut 3-4 times to fully tighten the stand. If you don't do this your stand may not sit squarely on the floor. Don't over tighten.

### STEP 1

Attach vertical legs to base plate (finger tighten only)

### STEP 2

Attach bottom brace plate to vertical legs (finger tighten only)

### STEP 3



Attach the mat hanger assemblies to either side of the vertical legs (finger tighten only). Ensure that the hanger assembly arms are sloping upward so that they retain the mats.

### STEP 4

Gradually tighten all 10 bolt/nut assemblies. You don't need to over tighten.

### STEP 5

To ensure stability of the stand during loading and unloading it is recommended that you fasten the base or side bar to the floor or wall. A 10kg plate on each foot will provide stability if fixing is unviable.



## INSTRUCTIONS FOR USE

**It is essential that mats are placed and removed carefully from the stand. Position them single on alternate sides for stability.**



You have 10 x Hex Head bolt/nut for assembly

Ensure you have the correct pack – tall or short as per your invoice or packing slip. The overall length is the giveaway. The tall will be around 2m in length while the short will be about 1m.

Each pack will include:

- 2 x base plates (rectangular tube) with plastic end caps inserted (4 caps)
- 1 x bottom brace plate
- 2 x vertical square tube legs with plastic end cap inserted in the top (2 caps)
- 10 x bolts (hex head cap) and nuts
- 2 x mat hanger assemblies

**NOTE: To assemble you will require a 5 mm Allan key and a 10mm spanner.**